



SMARTElectrode 15.0.0.0

What's New



Enhancement

What

- BREAKING CHANGE
- Consider contour height on calculation of default start- and secure-position.
<https://redmine.buw-soft.de/issues/13762>


Why

- Calculation of default start and secure position using EDM_ORIGIN led to disadvantageous or wrong values.
- Reduce effort to set start and secure positions.


How

- **NOTE:** Adjustment of operation default planes may be necessary to respond appropriately to the new behavior.
- New behavior is available for all assemblies from current versions.

Current Behavior



New Behavior



Enhancement

What


- Introduce new option #Electrode #LATERAL_KEEPOUT_OF_BASE
<https://redmine.buw-soft.de/issues/13766>

Why

- Defines the minimum distance in XY direction from the base that must not be disturbed by workpiece geometry.

How

- Default value '0'
- When adding a new base, position will be adjusted to
 - meet normal distance D1 and
 - to fulfill lateral offset defined in LATERAL_KEEPOUT_OF_BASE



Enhancement

What


- Introduce new option #Electrode #SOLID_CONTOUR_CLEARANCE
<https://redmine.buw-soft.de/issues/13765>

Why

- Necessary to specify the minimum clearance in XY direction between the contour and blank outline

How

- Option value SOLID_CONTOUR_CLEARANCE defines the clearance added to electrode's solid contour before blank size selection.
- Default value '0'



Improvement

What

- Allow enabling or disabling automatic calculation of a variable measure in the Base UI. <https://redmine.buw-soft.de/issues/13672>
- (related to: <https://redmine.buw-soft.de/issues/12517>)

Why

- Allows users to switch between both behaviors

How

1. **Variable dimension used (-1)**
Variable dimension will be disabled and calculated automatically based on other inputs.
2. **Blank unlocked**
Z position of blank length should stay fixed on input.
Change of D2 changes D2 and D3.
Change of Z position changes LENGTH and D3 accordingly.
Change of LENGTH changes LENGTH and D3 accordingly.
3. **Blank locked**
Blank (A_BASE, B_BASE, LENGTH and D2) are disabled and can't be changed. Changes to D1, D3 or Z position change the other two dependent values accordingly.

Blank

Type: RECTANGULAR_BASE_FRAME

Size: 15X15

Locked: Blank Free Dim

A_BASE: 15.000 D1: 5.128

B_BASE: 15.000 D2: 22.000

Length: 30.000 D3: 0.022

Chamfers: 1.000 0.200

Frame: 5.000 1.000

Blank

Type: RECTANGULAR_BASE_FRAME

Size: 15X15

Locked: Blank Free Dim

A_BASE: 15.000 D1: 5.128

B_BASE: 15.000 D2: 22.000

Length: 30.000 D3: 0.022

Chamfers: 1.000 0.200

Frame: 5.000 1.000

Blank

Type: RECTANGULAR_BASE_FRAME

Size: 15X15

Locked: Blank Free Dim

A_BASE: 15.000 D1: 5.128

B_BASE: 15.000 D2: 22.000

Length: 30.000 D3: 0.022

Chamfers: 1.000 0.200

Frame: 5.000 1.000

Enhancement

What

- Allow export of files for Creo View
<https://redmine.buw-soft.de/issues/13699>

Why

- Provide data for downstream processes

How

- Use keywords “SE_EDM_BACKUP_PVS” or “SE_EDM_BACKUP_PVZ” in export template to create a file structure for Creo View (PVS) or a zipped archive of the files (PVZ). PVS creates a *.pvs for the file structure and numerated *.ol files containing viewable geometry.
- Example: export PVS/PVZ of assembly

```
Assembly PVS: #SE_EDM_BACKUP_DIR#\#partname#. #SE_EDM_BACKUP_PVS#  
Assembly PVZ: #SE_EDM_BACKUP_DIR#\#partname#. #SE_EDM_BACKUP_PVZ#
```

- Example: export PVS/PVZ for each electrode

```
ELECTRODE_START  
PVS: #SE_EDM_BACKUP_DIR#\#partname#. #SE_EDM_BACKUP_PVS#  
PVZ: #SE_EDM_BACKUP_DIR#\#partname#. #SE_EDM_BACKUP_PVZ#  
ELECTRODE_END
```

Enhancement

What

- Use default profiles or option files for 3D exports
<https://redmine.buw-soft.de/issues/13681>

Why

- Support of custom option files

How

- Save options file named “def_profile” to export/<type> or processor/<type>.

Type	Keyword in export template	Options file name
VDA	SE_EDM_BACKUP_VDA	def_profile.dep_vda
STEP	SE_EDM_BACKUP_STEP	def_profile.dep_step
IGES	SE_EDM_BACKUP_IGES	def_profile.dep_iges
CATIA	SE_EDM_BACKUP_CATIA	def_profile.dep_catv5
SAT (Acis)	SE_EDM_BACKUP_SAT	def_profile.dep_acis
NEUTRAL	SE_EDM_BACKUP_NEUTRAL	def_profile.dep_neu
X_T (Parasolid)	SE_EDM_BACKUP_X_T	def_profile.dep_para
UG (NX)	SE_EDM_BACKUP_UG	def_profile.dep_nx
JT (license necessary)	SE_EDM_BACKUP_JT	def_profile.dep_jt

Enhancement

What





- Edit CMM points in user interface
- <https://redmine.buw-soft.de/issues/12392>

Why

- Move measuring points to even value

How

- Open “CMM points”
- Select point to edit in table
- Start edit on double-click or press “Edit”
- Point will be automatically moved to new position or reachable coordinates are suggested if point is out of bounds
- Original coordinates are restored on cancel



Enhancement


What

- Allow CMM points in workpiece models
- <https://redmine.buw-soft.de/issues/12327>

Why

- Enable definition and output of measuring points for CMM in workpieces

How



Workflow and functionality is the same as for electrodes

- Activate component
- Open “CMM points”
- “Add” measuring points on pick position till loop is cancelled with MMB
- Confirm or discard points

The image shows a dialog box titled 'Measuring Points' with a table of data. The table has columns for ID, X, Y, Z, I, J, and K. The data is as follows:

ID	X	Y	Z	I	J	K
1	26.17	5.98	2.57	0.81	0.26	0.95
2	29.11	2.26	83.61	0.97	0.09	0.24
3	26.32	2.81	5.24	0.80	1.00	0.05

