

Creo Intelligent Fastener 9.0.4.0







Fixes

Parameter values for the 'BUW_*_ID*' fastener component parameters were set to '0' during redefinition.





Creo Intelligent Fastener 9.0.3.0







Fixes

- The creation of holes was improved. If an edge was hit on the exit surface, the hole was not created. SPR-13818141, C-16381450
- For inserts, the pitch 'P' was used instead of 'P1' to determine the hole thread series.
- Fixed a problem related to redefining fasteners in subassemblies.
- An issue related to the placement of fasteners on assembly cut surfaces has been fixed. SPR-14146142, C-16584416
- Fixed an error when reading *.dat files. If there was a space in the first column, there were problems when placing fasteners. *SPR-14131006, SPR-14130745, C-16573455*



Creo Intelligent Fastener 9.0.2.0





Fixes

- Fixed an error when reading *.dat files with #FAMTAB.
- The problem with redefining a screw with an insert has been fixed. The 'BASIC_DIAM' and 'THREAD' diameters of the screw instead of the insert were used to get the hole chart.
- Problem with resetting the hole note fixed. The 'RUN_MAPKEY_*' options have been removed. New API is used to reset the note. SPR-13760849
- Fixed problem with *.dat file having lines with the empty tabs. In this case the size was shown as 0 (zero). *SPR-13807791*
- Fixed reading of hole charts regarding 12 or 18 columns. SPR-13804155
- Remove blanks at the end of an instance name.



Creo Intelligent Fastener 9.0.1.0







Enhancements

- SPR 13264653 Set thread depth to 'Through Thread' if a hole with through thread is selected. SPR 13567673
- If a translation file is missing, the name of the file is output in the trail file.

Fixes

- SPR 13773021 Fixed problem with hole tables while creating and redefining a dowel pin.
- SPR 13773021 Fixed Creo crash when Redefine a screw fastener.
- C16322899 Fixed problem with the determination of the minimum and maximum diameter of the countersink.



Creo Intelligent Fastener 9.0.0.0



Enhancements



Enhancements

- SPR 11357093: Support unicode characters in param_relation.txt.
- SPR 11285257: Disallow thread-surfaces as a position reference.
- Add new INCREMENT_* options to control the increment value of the spin box for diameter and depth values.
- Support body colors for 2D-preview.